

Reprint exhibition wall “Fabric Wall”

How to create your print file



File setting

Format:	final format or scaled (e.g. 1:2)
Resolution:	ratio 1:1 96-150 dpi ratio 1:2 192-300 dpi ratio 1:10 960-1500 dpi
Bleed:	no
Crop marks:	no
Overprint:	deactivated
Fonts:	embedded or converted to paths
Do not use:	clipping paths, alpha channels, masks in PSD



File formats

Digital- and large format printing:

- PDF X-3*, TIFF, JPG, PSD (flattened to background layer), EPS*, AI*

*important notice

The file formats can be created with different programs with various attributes. That can cause numerous errors, e.g. deviation of colours, missing or incorrect fonts, missing elements etc.

To avoid such problems please create your data as a ready to print file in PDF / X-3:2002. To prevent incorrect printing, please feel free to send or upload your original file's preview (JPG) for comparison.



Colors

Color mode: CMYK
Color profile: ISO Coated v2, Coated Fogra 27/39

Do not use:

RGB and spot colors such as Pantone, HKS and RAL. They will be converted / simulated to CMYK. We cannot guarantee for color differences caused by conversion.

Proof

It is not possible to do color adjustments in the RIP software or at the printer. If color accuracy has high priority, we recommend you a proof beforehand.

The file can be created with several different versions of the color (e.g. small squares with the corresponding CMYK values).

We produce a colorbinding proof on the original material with the original colors. If necessary, you have the opportunity to adjust your file before print.



Notes

- We print and produce with a tolerance up to 0,25%, so the size could differ.
- We could not guarantee precisely sizes by millimeter.
- According to the file format, color anomalies may occur.

File upload



upload to our server

Please register in our onlineshop: www.werbecenter-onlineshop.de
When you finished the ordering process, you can upload your artwork directly in our upload-center.



e-mail

daten@werbecenter-berlin.de




by mail

Advertising & Displays
Werbecenter-Berlin GmbH
Zitadellenweg 26b
D-13599 Berlin
Germany

Reprint exhibition wall “Fabric Wall”

How to create your print file *(all measurements in cm)*



Reprint exhibition wall “Fabric Wall”

How to create your print file *(all measurements in cm)*



Reprint exhibition wall “Fabric Wall”

Installation guideline “Fabric Wall”

Product contents

1x digital print

Note


We recommend to assemble this pop up wall with two people.




Open the trolley and the bag...



...take out the exhibition wall.



Open it carefully and slowly with the Velcro tape facing upwards. Please handle with care.



Once the frame is fully opened, join the connection clips together from the outside to the inside. Lock them all carefully, to achieve the final stability.



Unfold the printed fabric with the loop tape. To attach it on the pop up frame with the hook tape, start in the corners and fasten it carefully once around.

**Disassembly Guideline “Fabric Wall”:**

The removal takes place in the reverse order and without any exertion. Place the exhibition wall back on the floor with the printed fabric facing upwards and remove the textile banner completely. Then open all clip connections from picture 6. The system automatically collapses into itself and can now be folded gently. If it does not work check if all clips are open and separated.

Product pictures can differ.